Relay Output Delay Time	* Master code # 4 0~99 # *
To set door relay strike time Door Open Detection	0-99 is to set the door relay time 0-99 seconds
Door Open Too Long (DOTL) warning. When used with an optional magnetic contact or built-in magnetic contact of the lock, if the door is opened normally, but not closed after 1 minute, the inside buzzer will beep automatically to remind people to close the door and continue for 1 minute before switching off automatically.	
Door Forced Open warning. When used with an optional magnetic contact or built-in magnetic contact of the lock, if the door is forced open, or if the door is opened after 20 seconds ,the inside buzzer and alarm output will both operate. The Alarm Output time is adjustable between 0-3 minutes with the default being 1 minute.	
To disable door open detection.	6 0 #
(Factory default)	
To enable door open detection	6 1 #
Alarm output time	
To set the alarm output time (0-3 minutes)	5 0~3 #
Factory default is 1 minute	
Keypad Lockout & Alarm Output options. *If there are 10 invalid cards or 10 incorrect PIN numbers in a 10 minute period either the keypad will lockout for 10 minutes or both the alarm and the inside buzzer will operate for 10 minutes, depending on the option selected below.*	
Normal status: No keypad lockout) or alarm (factory default	7 0 # (Factory default setting)
Keypad Lockout	7 1 #
Alarm and inside buzzer operate	7 2 #
To remove the alarm	
To reset the Door Forced Open warning	Read valid card or Master Code #
To reset the Door Open Too Long warning	Close the door or Read valid card or Master Code #

In this mode the unit supports a Wiegand 26 bit output so the Wiegand data lines can be connected to any controller which supports a Wiegand 26 bit input.

Please note. That there is no LED activation in this configuration.



CODE-2651 Series

Standalone Keypad Access Control

USER MANUAL

code

ACCESS CONTROL

Product Specification

Packing List

Name	Qty	Note
Keypad	1	Access Controller
User manual	1	Documentation
Screw driver	1	Φ20mm×60mm,Special for keypad
Rubber plug	2	Φ6mm×30 mm, used for fixing
Self tapping screws	2	Φ4mm×28 mm, used for fixing
Star screws	1	Φ3mm×6mm, used for fixing

Specification

Operating Voltage	DC 12V±10%
User Capacity	2000
Card Reading Distance	3-6 cm
Active Current	<60mA
Idle Current	25±5 mA
Lock Output Load	Max 3A
Alarm Output Load	Max 3A
Operating Temperature	-45°C ~ 60°C
Operating Humidity	10%- 90% RH
Waterproof	Conforms to IP68
Adjustable Door Relay time	0 - 99 seconds
Adjustable Alarm Time	0 - 3 minutes
Wiring Connections	Electric Lock, Exit Button, External Alarm,External reader

Wiring Connections

Colour	Function	Description
Pink	BELL_A	Doorbell button one end
Pale blue	BELL_B	Doorbell button to the other end
Green	D0	WG output D0
White	D1	WG output D1
Grey	ALARM	Alarm negative(alarm positive connected 12 V+)
Yellow	OPEN	Exit button one end(the other end connected GND)
Brown	D_IN	Magnetic switch one end(the other end connected GND)
Red	12V+	12V + DC Regulated Power Input
Black GND	12V -	DC Regulated Power Input
Blue	NO	Relay normally-on end (Connect positive electric lock "-")
Purple	COM	Relay Public end, connect GND
Orange	NC	Relay Closed end (connect negative electric lock "-")



Installation Procedure

STEP 1

Remove the back cover from the keypad using the supplied special screw driver

STEP 2

Gently pull the metal back plate cover away from the main body of the reader.

STEP 3



- Drill 2 holes on the wall for the Self tapping screws and I hole for the cable
- Put the supplied rubber bungs to into the two holes
- Fix the back cover firmly on the wall with 2 Self tapping screws
- Thread the cable through the cable hole
- Attach the keypad to the back cover.

Quick Reference Programming Guide

To enter the programming mode	* Master code #
	999999 is the default factory master code
To exit from the programming mode	*
Note that to undertake the following programming the master user must be logged in	
To change the master code	0 New code # New code #
	The master code can be 6 to 8 digits
To add a PIN user.	1 User ID number # PIN #
	The ID number is any number between 1 & 2000.
	The PIN is any four digits between 0000 & 9999 with the
	exception of 1234 which is reserved. Users can be
	added continuously without exiting programming mode
To add a card user	1 Read Card #
	Cards can be added continuously without exiting
	programming mode
To delete a PIN or a card user.	2 User ID number # for a PIN user or
	2 Read Card # for a card user
	Users can be deleted continuously without exiting
	programming mode
To unlock the door for a PIN user	Enter the PIN then press #
To unlock the door for a card user	Present the card

To Reset to Factory Default

A

Disconnect power from the unit

B.

Press and hold # key whilst powering the unit back up

C.

On hearing two "Di" release # key, system is now back factory settings

Anti Tamper Alarm

The unit uses a LDR (light dependent resistor) as an anti tamper alarm. If the keypad is removed from the cover then the tamper alarm will operate.

Sound and Light indication

Operation Status	Red Light	Green Light	Yellow Light	Buzzer
Power on	-	Bright	-	Di
Stand by	Bright	-	-	-
Press keypad	-	-	-	Di
Operation successful	-	Bright	-	Di
Operation failed	-	-	-	DiDiDi
Enter into programming mode	Bright	-	-	
In the programming mode	-	-	Bright	Di
Exit from the programming	Bright	-	-	Di
Open the door	-	Bright	-	Di
Alarm	Bright	-	-	Alarm

Other products in the range

Code	Description	
CODE-ME12	1 or 2 door controller with Ethernet connection	
CODE-MS12	1 or 2 door controller with Serial connection	
CODE-ME24	2 or 4 door controller with Ethernet connection	
CODE-MS24	2 or 4 door controller with Serial connection	
CODE-6800	5 Amp Power supply in Metal Box Enclosure	
CODE-FC02	Card Distributor	
CODE-MF01	Mifare Card	

Concept Pro

Detailed Programming Guide - User Settings

To enter the programming mode	* Master code #
	999999 is the default factory master code
To exit from the programming mode	*
Note that to undertake the following programming the master user must be logged in	
To change the master code	0 New code # New code #
	The master code can be 6 to 8 digits long
Setting the working mode:	
Set valid card only users	3 0 # Entry is by card only
Set valid card and PIN users	3 1 # Entry is by card and PIN together
Set valid card or PIN users	3 2 # Entry is by either card or PIN (default)
To add a user in either card or PIN mode, i.e. in the 3 2 # mode. (Default setting)	
To add a Pin user	1 User ID number # PIN #
	The ID number is any number between 1 & 2000. The PIN is any four digits between 0000 & 9999 with the exception of 1234 which is reserved. Users can be added continuously without exiting programming mode as follows:
	1 User ID no 1 # PIN # User ID no 2 # PIN #
To delete a PIN user	2 User ID number #
	Users can be deleted continuously without exiting programming mode
To change the PIN of a PIN user *(This step must be done out of programming mode)*	* ID number # Old PIN # New PIN # New PIN #
To add a card user (Method 1) *This is the fastest way to enter cards, user ID number auto generation.*	1 Read card #
	Cards can be added continuously without exiting programming mode
To add a card user (Method 2) *This is the alternative way to enter cards using User ID Allocation. In this method a User ID is allocated to a card. Only one user ID can be allocated to a single card*	1 ID number # Read card #
	User can be added continuously without exiting programming mode
To add a card user (Method 3) *In this method a User ID is allocated to a card number. Only one user ID can be allocated to the card number.*	1 ID number. # Card number. #
	User can be added continuously without exiting programming mode

To delete a card user by card. Note users can be deleted continuously without exiting programming mode.	2 Read Card #
To delete a card user by user ID. This option can be used when a user has lost their card.	2 User ID #
To delete a card user by card number. This option can be used when the user want to make the change but the card lost.	2 Card number #
	Note users can be deleted continuously without exiting programming mode
To add a card and PIN user in card and PIN mode (3 1 #)	
Add a card and Pin user (The PIN is any four digits between 0000 & 9999 with the exception of 1234 which is reserved.)	Add the card as for a card user
	Press * to exit from the programming mode
	Then allocate the card a PIN as follows:
	* Read card 1234 # PIN # PIN #
To change a PIN in card and PIN mode (Method 1) Note that this is done outside programming mode so the user can undertake this themselves	* Read Card Old PIN # New PIN # New PIN #
To change a PIN in card and PIN mode (Method 2) Note that this is done outside programming mode so the user can undertake this themselves	* ID number # Old PIN # New PIN # New PIN #
To delete a Card and PIN user just delete the card	2 User ID #
To add a card user in card mode	(3 0 #)
To Add and Delete a card user	The operating is the same as adding and deleting a card user in 3 2 #
To delete All users	
To delete ALL users. Note that this is a dangerous option so use with care	2 0000 #
To unlock the door	
For a PIN user	Enter the PIN then press #
For a card	User Read card
For a card and PIN user	Read card then enter PIN #